



burkert









A rotork Brand

Fine Controls have been supplying process controls & instrumentation equipment since 1994, & now serves an ever expanding customer base, both in the UK & globally.

We offer a full range of valve & instrumentation products & services, with our product rangerepresenting leading technologies & brands:

Flow: Flow Meters & Transmitters, Flow Switches, Flow Control Valves & Batch Control Systems

Temperature: Temperature Probes & Thermowells, Temperature ransmitters, Temperature Regulators & Temperature Displays

Level: Level Transmitters & Switches

Pressure: Pressure Gauges & Transmitters, Precision & High Pressure Regulators & I-P Converters, Volume boosters.

Precision Pneumatics: Pressure Regulators, I-P Converters, Volume Boosters, Vacuum Regulators

Valves: Solenoid & Pneumatic Valves, Control Valves & Positioners, Actuated Ball, Globe or Diaphragm Valves & Isolation Valves

Services: Repair, Calibration, Panel Build, System Design & Commissioning



A rotorik Brand



Honeywell



Baumer Group









Fine Controls (UK) LTD, Bassendale Road, Croft Business Park, Bromborough, Wirral, CH62 3QL UK Tel: 0151 343 9966 Email: sales@finecontrols.com

FAIRCHILD MODEL 4800A PNEUMATIC VOLUME BOOSTER Installation, Operation and Maintenance Instructions

The Fairchild Model 4800A volume booster is specifically designed to be used in conjunction with valve positioners on large control valve actuators to provide faster response than possible with the valve positioner alone. Deadband within the operation of the volume booster allows the positioner to make small incremental valve position changes in a highly stable manor without activating the volume booster valves. The integral bypass valve provides a means to control the response of the booster to match variations in valve positioner and actuator sizes.

The Model 4800A volume booster is a rugged precision instrument with key features providing reliable, efficient and stable operation. These include:

- Fixed deadband between the operation of the supply valve and exhaust valve providing accurate and stable final positioning of the valve.
- Integral bypass needle valve to optimize response time and stability.
- Soft seat supply and exhaust valves provide efficient leak free operation and prevents hunting when used with modern electronic feed & bleed type positioners
- Pressure balanced supply valve maintains deadband specification preventing changes in control characteristics when supply pressure changes.
- Damped diaphragm control chamber protects valves from damaging oscillation under high flow conditions.
- Two accessory ports connected to the outlet chamber provide convienent access to the outlet for additional control accessories and pressure monitoring.
- Tapped exhaust port for collecting exhaust air or for incorporation of a sliencer.



Table 1. Specifications

Maximum Supply Pressure	250 psig 17 Bar 1700 kPa
Maximum Signal Pressure	150 psig 10 Bar 1000 kPa
Ambient Temperature Limits	-40 to 180°F -40 to 80°C
Nominal Deadband	1.5 psig 1.0 bar 100 kPa
Connection Sizes	Signal - 1/4" Inlet & Outlet - 3/4", or 1" Exhaust - 3/4" Accessory - 1/4"
Connection Thread	NPT, BSPT or BSPP
Maximum Cv	Supply Valve - 9.0 Exhaust Valve - 9.0 Bypass Valve - 0.75
Weight	9.5 lb. 4.3 Kg

FAIRCHILD MODEL 4800A PNEUMATIC VOLUME BOOSTER Installation, Operation and Maintenance Instructions



Table 2. Material of Construction

Body	Die Cast Aluminum
Supply & Exhaust Valves	Aluminum/Nitrile Aluminum/Fluorocarbon (Optional)
Seal Plate	Zinc Plated Steel
Bypass Valve	Stainless Steel
Seats	Aluminum
Diaphragms	Nitrile on Polyester Fluorocarbon on Polyester (Optional)
Seals	Nitrile Fluorocarbon (Optional)
Springs	Stainless Steel
Fasteners	Zinc Plated Steel Stainless Steel (Optional)

Installation

You can mount the booster in any position without affecting it's operation.

Clean all pipelines to remove dirt and scale before installation.

Apply a minimum amount of pipe compound to the male threads of the fitting only. **Do Not use Teflon tape as a sealant.** Start with the third thread back and work away from the end of the fitting to avoid contaminating the booster. install the booster in the air line.

The Inlet and Outlet are labeled "IN" and "OUT". Tighten all connections securely. Avoid undersized fittings that will limit the flow through the booster. For more information, see Figure 1.

CAUTION - Exhaust Port Restriction Excessive exhaust restriction can damage the diaphragms and valves within the volume booster. High flow capacity exhaust silencers and full size exhaust piping must be used to limit back pressure during the exhaust cycle operation.

FAIRCHILD MODEL 4800A PNEUMATIC VOLUME BOOSTER Installation, Operation and Maintenance Instructions



Figure 3 Typical Volume Booster with Single Acting Positioner and Diaphragm Actuator

MAINTENANCE

WARNING Shutting off air supply to the volume booster and adjacent equipment can create dangerous system conditions.

To clean the Model 4800A, use the following steps:

- 1. Shut off system pressure to the booster and carefully relieve the pressure in all connected lines. It is not necessary to remove the booster from the air line.
- 2. Remove the six Bolts from the bottom of the unit. For more information, see Figure 4.
- Remove the Inner Valve Assembly. The Valve Assembly will extract freely for about 1". The Assembly must then be pulled out of the Valve Body to unseat the Valve Seat. For more information, see Figure 4.
- 4. Wash the Inner Valve Assembly with a solvent. Exercise care to prevent damage to diaphragms and valve facings. Avoid solvents such as acetone, carbon tetrachloride and trichloroethylene.
- 5. Lubruicate the o-rings and replace the Valve Assembly carefully. Ensure that the Vent in the exterior part of the Inner Valve Assembly is clear. For more information, see Figure 4.

Trouble shooting

Problem	Source	Solution
Leakage	Body Bolts	Tighten the Body Bolts
High Bleed	 Relief Valve Supply Valve Supply Seat 	 If contaminated, clean the source and Body.
	 Diaphragm Assembly 	 If damaged, install the service kit.

NOTE: If the standard maintenance procedure does not correct the problem, install the appropriate service kit.

• 21151-1N

N 1:1 Ratio, Nitrile Elastomer & By-pass

• 21151-1J 1:1 Ratio, Fluorocarbon Elastomer & By-pass





Fairchild Products Company 3920 West Point Blvd. • Winston-Salem, NC 27103 phone: (336) 659-3400 • fax: (336) 659-9323 sales@fairchildproducts.com • www.fairchildproducts.com



LEGAL NOTICE:

The information set forth in the foregoing Installation, Operation and Maintenance Instructions shall not be modified or amended in any respect without prior written consent of Fairchild Industrial Products Company. In addition, the information set forth herein shall be furnished with each product sold incorporating Fairchild's unit as a component thereof.



IS-2004800A Litho in USA Rev B 03/10